







Direct application of parquet / laminate

System E-NERGY CARBON PET

1 Parquet / Laminate (floating installation)

2 E-NERGY CARBON PET


0.4 mm

3 Impact sound insulation / underlay e.g. CF DIRECT 1.5 1.5 mm


4 Edge insulation strips EPS | NEO

Moisture barrier if necessary

2 mm



Without additional thermal insulation









Prepare level, clean, load-bearing substrate. Dry screeds and wood-based panels must always be laid in two layers and offset



Wooden beam ceilings must be torsion-resistant and deflection-free



For adhesive and product recommendations see material approvals



The technical values are indicative and depend on the manufacturer and the used materials can vary. The manufacturer's instructions and generally accepted rules of technology must always be observed.

Cutting edges at the head and foot ends as well as at recesses for protection against leakage currents (e.g. through an aluminium-coated underlay) completely with insulating adhesive tape according to the installation instructions.