

Material releases wall / ceiling

Heating foil E-ENERGY CARBON FLEECE

Caution: Install E-ENERGY CARBON according to the installation instructions. Only use plastic spatula to press in the heating foil. Avoid kinks and folds. After installing the heating foil, a complete covering layer (filler, plaster system, tile, etc.) of at least 2 mm must be applied. Use recommended products in accordance with the manufacturer's instructions and the generally recognised rules of technology. **TIP:** Check in the manufacturer's instructions when the heating system can be put into operation. In the case of tile coverings, this can take up to 28 days.

Tiles / Natural stone		Ceramic tiles / porcelain stoneware	Natural stone
Primer		Rywalit Tiefengrund Rapid	
If required	Mould removal	-	
	Compensation	Rywalit GF 40 S Gradient and levelling filler	
	Primer on balance	Rywalit Tiefengrund Rapid	
Thermal Decoupling*		-	
Embedding heating foil		Rywalit FK X / FK X Schnell Flexible adhesive	
Sealing in damp areas		Rywalit DS 99 X Turbo / DS 01 X Turbo flexible sealing slurries	
Adhesive covering / top layer		Rywalit FK X / FK X Schnell Flexible adhesive	Rywalit MK Weiß marble adhesive
Jointing mortar		Rywalit Perfuge / FFX Plus flex joint	Rywalit NF natural stone joint

* A professional dew point calculation must be carried out when applying interior heat insulation to exterior walls. The manufacturer's instructions must be observed.

Material releases floor

Heating foil E-ENERGY CARBON FLEECE

Caution: Install E-ENERGY CARBON according to the installation instructions. Only use plastic spatula to press in the heating foil. Avoid kinks and folds. After installing the heating foil, a complete covering layer (filler, plaster system, tile, etc.) of at least 2 mm must be applied. Use recommended products in accordance with the manufacturer's instructions and the generally recognised rules of technology. **TIP:** Check in the manufacturer's instructions when the heating system can be put into operation. In the case of tile coverings, this can take up to 28 days.

Tiles / Natural stone	Ceramic tiles / porcelain stoneware	Natural stone
Primer	Rywalit Tiefengrund Rapid	
If required Compensation	Rywalit NA 20 / SK 12 Ground levelling compounds	
If required Primer on balance	Rywalit Tiefengrund Rapid	
Decoupling / Stiffening	Technicel® TEM 100 Decoupling path	
Embedding heating foil	Rywalit FK X / FK X Schnell Flexible adhesive	
Sealing in damp areas	Rywalit DS 99 X Turbo / DS 01 X Turbo flexible sealing slurries	
Adhesive coating	Rywalit FK X / FK X Schnell Flexible adhesive	Rywalit MK Weiß marble adhesive
Jointing mortar	Rywalit FFX Plus flex joint	Rywalit NF natural stone joint