

Material releases wall / ceiling

Heating foil E-ENERGY CARBON FLEECE

Caution: Install E-ENERGY CARBON according to the installation instructions. Only use plastic spatula to press in the heating foil. Avoid kinks and folds. After installing the heating foil, a complete covering layer (filler, plaster system, tile, etc.) of at least 2 mm must be applied. Use recommended products in accordance with the manufacturer's instructions and the generally recognised rules of technology. **TIP:** Check in the manufacturer's instructions when the heating system can be put into operation. In the case of tile coverings, this can take up to 28 days.

Covering / Top layer		Putty
Primer		SCHÖNOX SHP for old tiles and slabs, ceramic SCHÖNOX VD for mineral substrates, plasterboard
If required	Mould removal	–
	Compensation	SCHÖNOX aDECO KS, SCHÖNOX A6, SCHÖNOX RDF
	Primer on balance	–
	Thermal Decoupling*	–
Embedding heating foil		Laying according to manufacturer's instructions and embedding in with SCHÖNOX aDECO KS with 4x4 or aDECO KS coarse toothing
Sealing in damp areas		
Covering / surface layer		SCHÖNOX aDECO KS, SCHÖNOX A6, SCHÖNOX RDF

* A professional dew point calculation must be carried out when applying interior thermal insulation to exterior walls. The manufacturer's instructions must be observed.

Material releases floor

Heating foil E-ENERGY CARBON FLEECE

Caution: Install E-ENERGY CARBON according to the installation instructions. Only use plastic spatula to press in the heating foil. Avoid kinks and folds. After installing the heating foil, a complete covering layer (filler, plaster system, tile, etc.) of at least 2 mm must be applied. Use recommended products in accordance with the manufacturer's instructions and the generally recognised rules of technology. **TIP:** Check in the manufacturer's instructions when the heating system can be put into operation. In the case of tile coverings, this can take up to 28 days.

Wood floors		Parquet
Primer		SCHÖNOX SHP at: Mastic asphalt according to DIN EN 13813 (AS) (not applicable if sanding is sufficient) SCHÖNOX VD at: Cement screed according to DIN EN 13813 (CT), calcium sulphate or Calcium sulphate flowing screed according to DIN EN 13813(CA/CAF), dry screeds
If required	Compensation	SCHÖNOX HS 10, SCHÖNOX HS 10 F or SCHÖNOX HS 50 with dry screed: SCHÖNOX HS 10 or SCHÖNOX HS 10 F
	Primer on balance	–
Embedding heating foil		1. Bonding the heating foil with SCHÖNOX FS 2. Compensate on the heating foil with SCHÖNOX HS 10, SCHÖNOX HS 10 F and for dry screed with: SCHÖNOX HS 10, SCHÖNOX HS 10 F
Primer on embedded heating foil		–
Decoupling		–
Adhesive coating		SCHÖNOX® PARKETT 400 or SCHÖNOX® PARKETT 600

Tiles / Natural stone		Ceramic tiles / porcelain stoneware	Natural stone
Primer		SCHÖNOX SHP at: Mastic asphalt according to DIN EN 13813 (AS) (not applicable if sanding is sufficient) SCHÖNOX KH at: Cement screed according to DIN EN 13813 (CT), calcium sulphate or Calcium sulphate flowing screed according to DIN EN 13813(CA/CAF), dry screeds	
If required	Compensation	SCHÖNOX XP 15, SCHÖNOX SPF or SCHÖNOX FPL PLUS with dry screed: SCHÖNOX XP 15	
	Primer on balance	–	
Decoupling / Stiffening		–	
Embedding heating foil		Laying according to manufacturer's instructions and glue with SCHÖNOX Q6, SCHÖNOX Q9 W, SCHÖNOX Q12	
Sealing in damp areas		–	
Adhesive coating		SCHÖNOX® Q6, SCHÖNOX® Q9 W or SCHÖNOX® Q12	SCHÖNOX® Q9 W
Jointing mortar		SCHÖNOX® UF PREMIUM	SCHÖNOX® SU

Textile / elastic floor coverings		Textile coverings / needlefelt	PVC/CV coverings Design coverings
Primer		SCHÖNOX SHP at: Mastic asphalt according to DIN EN 13813 (AS) (not applicable if sanding is sufficient) SCHÖNOX VD at: Cement screed according to DIN EN 13813 (CT), calcium sulphate or Calcium sulphate flowing screed according to DIN EN 13813(CA/CAF), dry screeds	
If required	Compensation	SCHÖNOX HS 10, SCHÖNOX HS 10 F or SCHÖNOX HS 50 with dry screed: SCHÖNOX HS 10 or SCHÖNOX HS 10 F	
	Primer on balance	–	
Embedding heating foil		–	
Primer on embedded heating foil		1. Bonding the heating foil with SCHÖNOX FS 2. Compensate on the heating foil with SCHÖNOX HS 10, SCHÖNOX HS 10 F and for dry screed with: SCHÖNOX HS 10, SCHÖNOX HS 10 F	
Adhesive coating		Design flooring (LVT): SCHÖNOX® DUROCOLL Fibre-reinforced one-side dispersion adhesive PVC/CV, rubber, linoleum, textile: SCHÖNOX® EMICLASSIC® Universal - dispersion adhesive	