



## Material releases wall / ceiling

## Heating foil E-NERGY CARBON FLEECE

Caution: Install E-NERGY CARBON according to the installation instructions. Only use plastic spatula to press in the heating foil. Avoid kinks and folds. After installing the heating foil, a complete covering layer (filler, plaster system, tile, etc.) of at least 2 mm must be applied. Use recommended products in accordance with the manufacturer's instructions and the generally recognised rules of technology. TIP: Check in the manufacturer's instructions when the heating system can be put into operation. In the case of tile coverings, this can take up to 28 days.

Tiles / Natural stone		Ceramic tiles / porcelain stoneware	Natural stone
Primer		ASO-Unigrund-GE	ASO-Unigrund
required	Mould removal		-
	Compensation	SOLOPLAN-30-PLUS below the heating foil	
=	Primer on balance	ASO-UNIGRUND-GE	
Thermal Decoupling*		Steppboard-Platte 9 or 15 mm	
Embedding heating foil		MONOFLEX-XL or MONOFLEX-FAST	MONOFLEX-FAST or CRISTALLIT-FLEX
Sealing in damp areas		AQUAFIN-RS300	
Adhesive Covering / top layer		MONOFLEX-XL or MONOFLEX-FAST	MONOFLEX-FAST or CRISTALLIT-FLEX
Jointing mortar		CRISTALLFUGE-PLUS	

<sup>\*</sup> A professional dew point calculation must be carried out when applying interior heat insulation to exterior walls. The manufacturer's instructions must be observed.





## **Material releases floor**

## Heating foil E-NERGY CARBON FLEECE

Caution: Install E-NERGY CARBON according to the installation instructions. Only use plastic spatula to press in the heating foil. Avoid kinks and folds. After installing the heating foil, a complete covering layer (filler, plaster system, tile, etc.) of at least 2 mm must be applied. Use recommended products in accordance with the manufacturer's instructions and the generally recognised rules of technology. TIP: Check in the manufacturer's instructions when the heating system can be put into operation. In the case of tile coverings, this can take up to 28 days.

Tiles / Natural stone	Ceramic tiles / porcelain stoneware	Natural stone	
Primer	ASO-UNIGRUND-GE		
Compensation Primer	SOLOPLAN-30-PLUS		
Primer on balance	ASO-UNIGRUND-GE		
Decoupling / Stiffening	Steppboard-Platte 4, 9 or 15 mm		
Embedding heating foil	MONOFLEX-XL or MONOFLEX-FAST	MONOFLEX-FAST or CRISTALLIT-FLEX	
Sealing in damp areas	AQUAFIN-RS300		
Adhesive coating	MONOFLEX-XL or MONOFLEX-FAST	MONOFLEX-FAST or CRISTALLIT-FLEX	
Jointing mortar	Cristallfuge Plus		