

## Material releases wall / ceiling

### Heating foil E-ENERGY CARBON FLEECE

**Caution:** Install E-ENERGY CARBON according to the installation instructions. Only use plastic spatula to press in the heating foil. Avoid kinks and folds. After installing the heating foil, a complete covering layer (filler, plaster system, tile, etc.) of at least 2 mm must be applied. Use recommended products in accordance with the manufacturer's instructions and the generally recognised rules of technology. **TIP:** Check in the manufacturer's instructions when the heating system can be put into operation. In the case of tile coverings, this can take up to 28 days.

Tiles / Natural stone		Ceramic tiles / porcelain stoneware	Natural stone
Primer		For absorbent surfaces: <b>Baumit MultiPrimer</b> For non-absorbent surfaces (e.g. tiles): <b>Baumit SuperPrimer</b>	
If required	Mould removal	-	
	Compensation	-	
	Primer on balance	-	
Thermal Decoupling*		-	
Embedding heating foil		<b>Baumit Baumacol FlexTop</b>	
Sealing in damp areas		-	
Adhesive covering / top layer		<b>Baumit Baumacol FlexTop</b>	
Jointing mortar		-	

Covering / Top layer		Putty
Primer		For absorbent surfaces: <b>Baumit MultiPrimer</b> For non-absorbent substrates (e.g. tiles): <b>Baumit SuperPrimer</b>
If required	Mould removal	-
	Compensation	<b>Baumit multiContact MC 55 W</b>
	Primer on balance	-
Thermal Decoupling*		-
Embedding heating foil		<b>Baumit multiContact MC 55 W</b>
Sealing in damp areas		-
Covering / surface layer		<b>Baumit KlimaFinish, Baumit KlimaDekor, Baumit Klima EST 00, Baumit Klima EST 01, Baumit Klima Glätt W, Baumit multiFine RK 70 N</b>

\* A professional dew point calculation must be carried out when applying interior heat insulation to exterior walls. The manufacturer's instructions must be observed.